



439774



王樣花之語水果叉

439675



王樣花之語咖啡匙

460822

17.0 x 0.0 x 0.0



王樣花之語中餐叉



460860

16.7 x 0.0 x 0.0



王樣花之語中餐匙




460877

16.3 x 0.0 x 0.0



王樣花之語中圓匙



尺寸：長24.8x高0.7x寬0.0cm

466237

24.0 x 0.0 x 0.0



王樣花之語單雙316不鏽鋼筷



442491



王樣花之語316不鏽鋼筷5雙入

王樣 OSAMA(大餐匙)



453428



義式特級大餐匙

王樣 OSAMA(咖啡匙)



453466



義式特級咖啡匙

王樣 OSAMA(中餐匙)



王樣 OSAMA(牛奶匙)



王樣 OSAMA(大餐叉)



453442



義式特級中餐匙

453473



義式特級牛奶匙

453343



義式特級大餐叉



王樣OSAMA(小叉)



453367



4 719851 654558
義式特級小叉

王樣OSAMA(牛排刀)



453404



4 719851 654480
義式特級牛排刀

王樣OSAMA(奶油刀)



453398



4 719851 654589
義式特級奶油刀

王樣OSAMA(布丁匙)



453411



4 719851 654572
義式特級布丁匙

王樣OSAMA(小糖匙)



453480



4 719851 654596
義式特級小糖匙

王樣OSAMA(大圓匙)



453435



4 719851 654527
義式特級大圓匙

王樣OSAMA(中圓匙)



453459



4 719851 654534
義式特級中圓匙

幸運草(大圓匙)



453589



4 719851 655081
王樣幸運草大圓匙

幸運草(中圓匙)



453596



4 719851 652127
王樣幸運草中圓匙

幸運草(大餐匙)



453558



4 719851 655067
王樣幸運草大餐匙

幸運草(中餐匙)



453565



4 719851 655111
王樣幸運草中餐匙

幸運草(大餐叉)



453503



4 719851 655074
王樣幸運草大餐叉



愛屋族日用百貨股份有限公司－產品目錄

TEL:(04)2336-8800 FAX:(04)2336-8822

台中市烏日區五光路636號

P00609-003

幸運草(牛排刀)



453534



4 719851 655548
王樣幸運草牛排刀

幸運草(長茶匙)



453541



4 719851 655159
王樣幸運草長茶匙

幸運草(中餐叉)



453510



4 719851 652165
王樣幸運草中餐叉



J-485 規格：約17.2x3.4cm

002480

17.2 x 3.4 x 0.0



4 713106 391434
王樣幸運草葡萄柚匙

幸運草(小叉)



453527



4 719851 655135
王樣幸運草小叉

幸運草(小匙)



453572



4 719851 655142
王樣幸運草小匙

429348



4 713106 390222
王樣304法國(大)餐叉

429355



4 713106 390253
王樣304法國(中)餐叉

429362



4 713106 390260
王樣304法國(小)餐叉

429331



4 713106 390192
王樣304法國牛排刀

429430



4 713106 390284
王樣304法國(長)茶匙

429584



4 713106 390215
王樣304法國(大)餐匙



愛屋族日用百貨股份有限公司－產品目錄

TEL:(04)2336-8800 FAX:(04)2336-8822

台中市烏日區五光路636號

P00609-004

429447



4 713106 390291
王樣304法國(中)餐匙

429454



4 713106 390277
王樣304法國(小)餐匙

439668



4 713106 391304
王樣滿天星長茶匙

442507



4 713106 391403
王樣滿天星316不鏽鋼筷5雙入

310172



4 719851 654923
J00060王樣海尼湯匙

374396



4 719851 652950
J604王樣(日式)湯匙

410407



4 719851 659119
J603王樣日式(小)湯匙

350093



4 719851 655005
J605王樣(平底)湯匙

429492



4 719851 657504
王樣304水滴小台匙

429485



4 713106 390000
王樣304水滴中台匙

429461



4 719851 655180
王樣304(18CM)日式大台匙

429478



4 719851 659645
王樣304(21CM)日式大台匙



愛屋族日用百貨股份有限公司－產品目錄

TEL:(04)2336-8800 FAX:(04)2336-8822

台中市烏日區五光路636號

P00609-005



453381



4 713106 391595
王樣304白鐵筷23CM(6雙入)



19cm

457341



4 713106 391588
王樣304白鐵筷19CM(6雙入)

462222

21.4 x 1.2 x 0.0



4 713106 391502
J7094王樣304分菜夾



462239

30.0 x 0.0 x 0.0



4 719851 653506
J7053王樣通用服務夾大



462246

24.5 x 0.0 x 0.0



4 719851 653513
J7054王樣通用服務夾小



462253

25.3 x 4.0 x 0.0



4 719851 655784
J7065王樣如意夾大

286729



4 719851 654237
J00041王樣(大)湯杓

286705



4 719851 654244
J00042王樣(大空)湯杓

286736



4 719851 654251
J00043王樣(中)湯杓

286712



4 719851 654268
J00044王樣(中空)湯杓

286675



4 719851 651403
王樣(大)煎匙

290115



4 719851 654190
J00050王樣大菜匙



351199



4 719851 652967
J507王樣(不沾)黑鑽煎匙

353834



4 719851 652974
王樣(不沾空)黑鑽煎匙

354565



4 719851 652653
J10006日本(尖)刀鑽菜刀

354572



4 719851 652646
J10005日本(角)刀鑽菜刀

439743



4 589444 421023
金嘉美(101)咖啡濾紙100入

439750



4 589444 421061
金嘉美(102)咖啡濾紙100入

439767



4 589444 421146
金嘉美(103)咖啡濾紙100入

468453



4 713106 392509
王樣316真空手拎杯350ML黑

468460



4 713106 392516
王樣316真空手拎杯350ML灰

468477



4 713106 392523
王樣316真空手拎杯350ML金

468484



4 713106 392530
王樣316真空手拎杯470ML黑

468491



4 713106 392547
王樣316真空手拎杯470ML灰





愛屋族日用百貨股份有限公司－產品目錄

TEL:(04)2336-8800 FAX:(04)2336-8822

台中市烏日區五光路636號

P00609-007



468507 7.5 x 7.5 x 26.3

B-316-470-3(金) 尺寸:Ø10.5x25.5(高)cm



4 713106 392554
王樣316真空手拎杯470ML金



468514 8.0 x 8.0 x 29.8

B-316-700-1(黑) 尺寸:Ø12x29(高)cm



4 713106 392561
王樣316真空手拎杯700ML黑



468521 8.0 x 8.0 x 29.8

B-316-700-2(灰) 尺寸:Ø12x29(高)cm



4 713106 392578
王樣316真空手拎杯700ML灰



468538 8.0 x 8.0 x 29.8

B-316-700-3(金) 尺寸:Ø12x29(高)cm




4 713106 392585
王樣316真空手拎杯700ML金



429379



4 713106 390475
王樣琴音壺2.0L



429386



4 713106 390482
王樣琴音壺3.0L

429393



4 713106 390499
王樣琴音壺4.0L

429409



4 713106 390505
王樣琴音壺5.0L

429416



4 713106 390512
王樣琴音壺7.0L



460839 22.0 x 18.0 x 16.0



4 713106 392387
王樣316笛音壺2L



460846 22.6 x 20.0 x 26.5



4 713106 392394
王樣316笛音壺3L

461041 25.0 x 21.5 x 18.0



4 713106 392400
王樣316笛音壺4L



愛屋族日用百貨股份有限公司－產品目錄

TEL:(04)2336-8800 FAX:(04)2336-8822

台中市烏日區五光路636號

P00609-008



460853 25.7 x 22.3 x 28.5



4 713106 392417
王樣316音壺5L

王樣 OSAMA



19cm
厚度0.6mm

MIT台灣製造

458058



4 713106 392103
王樣304火鍋身19CM

王樣 OSAMA



24cm
厚度0.6mm

MIT台灣製造

458065



4 713106 392110
王樣304火鍋身24CM

王樣 OSAMA



28cm
厚度0.6mm

MIT台灣製造

458072



4 713106 392127
王樣304火鍋身28CM

王樣 OSAMA



B11020

304特厚火鍋/厚度1mm

457822



4 713106 392134
王樣304特厚火鍋身20CM

王樣 OSAMA



B11024

304特厚火鍋/厚度1mm

457839



4 713106 392141
王樣304特厚火鍋身24CM

王樣 OSAMA



B11026

304特厚火鍋/厚度1mm

457846



4 713106 392158
王樣304特厚火鍋身26CM

王樣 OSAMA



26cm 附蓋

457433



4 713106 392196
王樣304特厚火鍋26CM(附蓋)

王樣 OSAMA



28cm 附蓋

457440



4 713106 392202
王樣304特厚火鍋28CM(附蓋)



尺寸: Ø30cm

467425 41.0 x 30.0 x 13.0



4 713106 392868
王樣304特厚火鍋30CM(附蓋)